




Circuit Globe



From 96 on overload



# STAR-DELTA MOTOR STARTER LADDER LOGIC



### Control and power circuit for star-delta starter

